

Purezza Mattress and Upholstery Checklist

A short low-moisture cleaning workflow.

Before cleaning

- Check care label, material, seams, piping and damage.
- Test colourfastness and chemistry.
- Remove dry soil and protect flooring.

Extraction

- Work in small sections with minimum effective flow.
- Make one or two vacuum-only passes after each wet pass.
- Monitor recovered liquid through the transparent tool.

Drying

- Expose both sides to airflow.
- Check seams, piping and underside before handover.

Stage	Control
Inspection	No colour transfer and wet cleaning is allowed
Flow	Even moisture without soaking filling
Recovery	Visible liquid is minimal after dry passes
Drying	Both faces are completely dry

Important: follow material-care, chemical and electrical-safety instructions. Confirm current equipment specifications before work.