

# Furniture drying after cleaning: Purezza and SU-290

A short technician checklist for reducing residual moisture after extraction and organizing airflow.

## Workflow

- Inspect the fabric and test colourfastness.
- Select chemistry and the minimum effective solution flow.
- Make a wet Purezza pass followed by one or two vacuum-only passes.
- Move furniture from the wall and direct airflow along the upholstery.

## Equipment

- Purezza Scirocco Siaflo: up to 9 bar at a 0.15 nozzle according to the product card.
- Purezza Scirocco Aquatec: 15 bar and 3.8 l/min according to the product card.
- U3DP Clean SU-290: 290 W, 3,200 m<sup>3</sup>/h, 5 kg.
- Up to three SU-290 units can be connected in series when the circuit is suitable.

| Stage       | Control point                                                 |
|-------------|---------------------------------------------------------------|
| Extraction  | Avoid over-wetting; make vacuum-only passes after spraying.   |
| Positioning | Leave space from the wall and expose side surfaces.           |
| Drying      | Move air along the surface; do not overheat the material.     |
| Safety      | Check the 220 V circuit and avoid overloaded extension leads. |

Important: confirm current specifications and compatibility before ordering. Electrical work on 220 V equipment must be performed by a qualified technician.